

Xerox® VersaLink® C600 Color Printer

VersaLink C600 Color Printers are built on Xerox® ConnectKey® Technology. For more information, go to www.ConnectKey.com.



SYSTEM SPECIFICATIONS		VERSALINK 600
One-sided Speed¹ 8.5 x 11 in. A4 / 210 x 297 mm 8.5 x 14 in. / 216 x 356 mm	Up to 55 ppm color and black-and-white Up to 53 ppm color and black-and-white Up to 45 ppm color and black-and-white	
Two-sided Speed¹ 8.5 x 11 in. A4 / 210 x 297 mm 8.5 x 14 in. / 216 x 356 mm	Up to 52 ppm color and black-and-white Up to 50 ppm color and black-and-white Up to 26 ppm color and black-and-white	
Monthly Duty Cycle²	Up to 120,000 pages / month	
Recommended Average Monthly Print Volume³	Up to 17,000 pages	
Hard Drive	Optional 320 GB HDD	
Processor	1.05 GHz	
Memory	2 GB	
Connectivity	Ethernet 10/100/1000 Base-T, High-speed USB 3.0, Wi-Fi 802.11n and Wi-Fi Direct with optional Wi-Fi Kit (concurrent wired and wireless connections supported), NFC Tap-to-Pair	
Controller Features	Configuration Cloning, Xerox Extensible Interface Platform®, Xerox® App Gallery App, Xerox® Standard Accounting Tool, Network Accounting Enabled, Role Based Permissions, Convenience Authentication Enabled, Online Support	
User Interface Languages	English, French, Italian, German, Spanish, Brazilian Portuguese, Russian, Dutch, Swedish, Danish, Finnish, Norwegian, Greek, Turkish, Polish, Czech, Hungarian, Romanian, Catalan, Ukrainian, Croatian	
DEVICE SPECIFICATIONS		
ELECTRICAL REQUIREMENTS		
North America	Voltage: 110-127V +/-10% Frequency: 50/60 Hz +/-3%, 12A	
Europe and Other Geographies	Voltage: 220-240V +/- 10% Frequency: 50/60 Hz +/-3%, 8A	
POWER CONSUMPTION		
Continuous Printing⁵	800 watts or less	
Ready / Standby Mode⁵	85 watts or less	
Energy Saver / Sleep Mode⁵	0.65 watts or less	

OPERATING ENVIRONMENT				
Required Temperature Range (Storage)	32° to 95° F (0° to 35° C)			
Required Temperature Range (Operating)	50° to 90° F (10° to 32° C)			
Required Relative Humidity	15% to 85%			
Sound Power Levels Operating Standby	7.27 B(A) or less 4.84 B(A) or less			
Sound Pressure Levels Operating Standby	57.4 dB(A) or less, 33.5 dB(A) or less			
Boot Time (from Off to UI Ready)	As fast as 52 seconds			
Warm-up Time (from Sleep to UI Ready)	As fast as 11 seconds			
DIMENSIONS AND WEIGHT (UNPACKAGED)	WIDTH	DEPTH	HEIGHT	WEIGHT
Base Unit	16.9 in. / 427.4 mm	18.4 in. / 465.5 mm	17.5 in. / 443.4 mm	64.8 lb. / 29.4 kg
Base Unit with Additional 550-sheet Tray	16.9 in. / 427.4 mm	18.4 in. / 465.5 mm	22.3 in. / 566.4 mm	79.4 lb. / 36 kg
Base Unit with High Capacity Feeder	28.5 in. / 724.2 mm	30.4 in. / 772.1 mm	35.5 in. / 902.4 mm	108.2 lb. / 49.1 kg
Base Unit with High Capacity Feeder and Finisher	28.5 in. / 724.2 mm	30.4 in. / 772.1 mm	44.2 in. / 1121 mm	123.2 lb. / 55.9 kg
Base Unit with High Capacity Feeder and Mailbox	28.5 in. / 724.2 mm	30.4 in. / 772.1 mm	44.2 in. / 1121 mm	119.9 lb. / 54.4 kg
550-sheet Paper Tray	16.5 in. / 420 mm	18.3 in. / 464.5 mm	4.8 in. / 123 mm	4.1 lb. / 6.6 kg
High Capacity Feeder (includes Caster Base)	28.5 in. / 724.2 mm	30.4 in. / 772.1 mm	18.1 in. / 459 mm	43.4 lb. / 19.7 kg
Cabinet (includes Caster Base)	28.5 in. / 724.2 mm	30.4 in. / 772.1 mm	13.2 in. / 336 mm	37 lb. / 16.6 kg
Caster Base	28.5 in. / 724.2 mm	30.4 in. / 772.1 mm	3.5 in. / 90 mm	18.7 lb. / 8.5 kg
Mailbox	17.7 in. / 450.8 mm	18.8 in. / 477.6 mm	9.8 in. / 248.0 mm	11.7 lb. / 5.3 kg
Finisher	17.7 in. / 450.8 mm	16.2 in. / 411.0 mm	9.8 in. / 248.0 mm	15 lb. / 6.8 kg
DIMENSIONS AND WEIGHT (PACKAGED)	WIDTH	DEPTH	HEIGHT	WEIGHT
Base Unit	22.8 in. / 580 mm	25 in. / 634 mm	23.9 in. / 607 mm	77.2 lb. / 35 kg
550-sheet Paper Tray	21.1 in. / 535 mm	23 in. / 584 mm	9.8 in. / 248 mm	18.7 lb. / 8.5 kg
High Capacity Feeder (includes Caster Base)	22.4 in. / 568 mm	26.1 in. / 663 mm	28 in. / 711 mm	83.8 lb. / 38 kg
Cabinet (includes Caster Base)	23 in. / 584 mm	24.8 in. / 629 mm	23.5 in. / 597 mm	57.3 lb. / 28 kg
Caster Base	23 in. / 585 mm	24.4 in. / 619 mm	13 in. / 330 mm	39.7 lb. / 18 kg
Mailbox	22.6 in. / 573 mm	20.4 in. / 518 mm	15.2 in. / 386 mm	16.3 lb. / 7.8 kg
Finisher	22.6 in. / 573 mm	15.7 in. / 398 mm	15.2 in. / 386 mm	18.6 lb. / 8.8 kg
CERTIFICATIONS				
	To view the latest list of certifications, go to www.xerox.com/OfficeCertifications .			

Xerox® VersaLink® C600 Color Printer

PRINT	
First-Print-Out Time	As fast as 8 seconds color and black-and-white
Print Resolution	Up to 1200 x 2400 dpi
Page Description Languages	PCL® 5e, 6 PDF XPS TIFF JPEG HP-GL Adobe® PostScript® 3™
Maximum Print Area	4 mm from edge of paper
Print Features	<ul style="list-style-type: none"> Application Defaults Banner Pages Enable / Disable Bi-directional Real-time Status Booklet Layout Color Adjustments (lightness, contrast, saturation, color balance) Color Correction Draft Mode Fit to New Paper Size Job Identification (Print ID or Banner, Print ID in margins on first page only or all pages) Job Monitoring (Client or Local User Interface) N-up Page Layout (up to 16 pages per sheet) Paper Selection by Attribute Personal Print Print Around Enable / Disable Print from USB Run Black Sample Set Saved Job Scaling Secure Print Skip Blank Pages Special Pages (exception page programming: covers, inserts, exceptions pages) Store and Recall Driver Settings Stored Jobs Deletion Two-sided Printing Watermark (predefined and custom) Earth Smart Driver Settings
Print from USB	<ul style="list-style-type: none"> Allows walk-up printing from Type A USB port Supports direct printing from computer via Type B USB port Supported file formats: PDF, JPEG, TIFF, XPS, PDF/A
Operating Systems	<ul style="list-style-type: none"> Windows® 7, 8, 8.1, 10 Windows Server 2008 SP2, Server 2008 R2 SP1, Server 2012, Server 2012 R2, Server 2016 macOS® 10.11, 10.12, 10.13 Citrix® Redhat® Enterprise Linux® Fedora Core IBM® AIX® HP-UX® Oracle® Solaris SUSE® SAP® <p>Note: For information about supported versions for the above operating systems, please visit our Drivers & Downloads page and specify your device at www.support.xerox.com.</p>
Fonts	<ul style="list-style-type: none"> PostScript fonts: 136 PCL fonts: 83

Xerox® VersaLink® C600 Color Printer

Xerox® Global Print Driver®	A truly universal print driver that lets IT administrators install, upgrade and manage Xerox® and non-Xerox® devices from a single driver. It provides a consistent, easy-to-use interface for end-users, reducing the number of support calls, and simplifying print services management.
Xerox® Pull Print Driver	Makes it easy for IT managers to qualify, deploy and manage all print devices using a single driver in a Pull Print environment. Uses a single queue and single driver. The Xerox® Pull Print Driver extends convenience across a broad range of printing assets. IT administrators no longer need to manage and configure multiple drivers. Used in conjunction with Equitrac Office®, Ysoft® SafeQ®, Pharos® and others.
MOBILE SOLUTIONS AND MOBILE DEVICE APPS	
Apple® AirPrint®	Print email, photos and important office documents directly from an Apple iPhone® or iPad® with no drivers to install and no cables to connect. With AirPrint, an iPhone or iPad automatically locates and connects to the AirPrint-enabled device over the office Wi-Fi network.
Google Cloud Print™	Google Cloud Print connects print devices to the web, enabling users to print the applications they use every day from smartphones, tablets, Chromebook™ notebook computers and any other web-connected device.
Mopria® Certified	ConnectKey Technology-enabled print devices are Mopria® certified. Mopria® certification ensures you can print wirelessly from your Mopria® supported (Android) smart phone, tablet and other mobile devices instantly and easily.
Xerox® @printbyXerox	@printbyXerox App is a free service that allows secure printing from any email-enabled device (computer, phone, tablet, iOS, Android™, Google® Chromebook™ and more) to a Xerox® printer or MFP using a single email address with no IT intervention. No training is needed. End-users simply send attachments to the email address and release them at the MFP panel.
Xerox® Print Services plug-in for Android™ (Free at Google Play™ Store)	The Xerox® Print Services plug-in for Android KitKat (4.4 or greater) devices streamlines mobile printing without third-party apps or additional print drivers. You can easily print photos, web pages and documents when your mobile device is connected to printers or multifunction printers using a wireless network. A robust print option set includes two-sided printing, stapling and secure code release. A free download is available from the Google Play™ store.
Xerox® Workplace Suite and Xerox® Workplace Cloud	Xerox® Workplace Suite is a modular set of workflows designed to save customers time and money by providing effective control over their print fleet, while enabling worker productivity and mobility through a set of robust workflows. Xerox enables ultimate customer flexibility by offering these capabilities in both an on-premises server version (Workplace Suite) and with a cloud based-version (Workplace Cloud) of this solution.
SOFTWARE SOLUTIONS	
Xerox® ConnectKey Apps (Found at the Xerox App Gallery)	Increase user productivity by simplifying and shortening everyday tasks. Unlike traditional software, ConnectKey Apps do not require a dedicated server, PC or IT resource. Instead, simply download these lightweight, serverless ConnectKey Apps to the ConnectKey Technology-enabled device.

SECURITY	
Security Features	Access Controls AES 256-bit Encryption Audit Log Certificate Path Validation Certificate Revocation List (CRL) / Status Protocol (OCSP) Detection of External Program Falsification (XCP Plug-in) Cisco® Identity Services Engine (ISE) Integration Domain Filtering FIPS 140-2 Firmware Verification Immediate Disk Overwrite* IP Address Filtering IPsec Network Authentication Port Filtering Pre-installed Self-Signed Certificates Role Based Permissions Secure Print Security Certificate Management Smart Card Enablement (CAC/PIV/.NET) SNMPv3 Status Protocol (OCSP) TLS / SSL Trusted Platform Module (TPM) *Requires HDD / Productivity Kit
ACCOUNTING	
XEROX® STANDARD ACCOUNTING / NETWORK ACCOUNTING (STANDARD)	
Tracking	Print usage
Accounting	Xerox® Standard Accounting Tool Up to 1,000 User Accounts without HDD Up to 9,999 User Accounts with HDD Up to 500 General Accounts Network Accounting (Job Based Accounting) Up to 1,000 User IDs; Up to 1,000 Account IDs without HDD Up to 60,000 User IDs; Up to 60,000 Account IDs with HDD Up to 14,000 Accounting Records (transactions)
Features	<ul style="list-style-type: none"> Administrator can manage the feature via the Embedded Web Server.
ACCOUNTING OPTIONS – NETWORK ACCOUNTING (ALLOWS CENTRAL SERVER TO MANAGE ALL ACCOUNTING)	
	<ul style="list-style-type: none"> Enhanced network accounting with up to the minute data on how the system is being used Comprehensive management and enterprise scale tracking and reporting of device usage Numerous solutions are available through Xerox Alliance Partners. For details visit www.xerox.com Security enhancements include simultaneous support for HTTP/HTTPS protocols Device requests account authentication from third party server enabling larger databases of users and accounts Accept Authentication Login at control panel and pass to third party Networking Account
PAPER HANDLING	
BYPASS TRAY	
Capacity⁴	150 sheets
Sizes	Custom sizes: 3 x 5 in. to 8.5 x 14 in. / 76 x 127 mm to 216 x 356 mm
Weights One-sided: Two-sided:	16 lb. bond to 80 lb. cover / 60 to 220 gsm 16 lb. bond to 65 lb. cover / 60 to 176 gsm

Xerox® VersaLink® C600 Color Printer

Types	Bond Plain Paper Cardstock Custom	Envelopes Hole Punched Labels Letterhead	Lightweight Cardstock Pre-Printed Recycled
TRAY 1			
Capacity⁴	550 sheets		
Sizes	Custom sizes: 3 x 7.5 in. to 8.5 x 14 in. / 76 x 190 mm to 216 x 356 mm		
Weights One-sided: Two-sided:	16 lb. bond to 80 lb. cover / 60 to 220 gsm 16 lb. bond to 65 lb. cover / 60 to 176 gsm		
Types	Bond Plain Paper Cardstock Custom	Hole Punched Labels Letterhead Lightweight Cardstock	Heavyweight Cardstock Pre-Printed Recycled
UP TO FOUR ADDITIONAL TRAYS			
Capacity⁴	550 sheets		
Sizes	Custom sizes: 3 x 7.5 in. to 8.5 x 14 in. / 76 x 190 mm to 216 x 356 mm		
Weights One-sided: Two-sided:	16 lb. bond to 80 lb. cover / 60 to 220 gsm 16 lb. bond to 65 lb. cover / 60 to 176 gsm		
Types	Bond Plain Paper Cardstock Custom	Hole Punched Labels Letterhead Lightweight Cardstock	Heavyweight Cardstock Pre-Printed Recycled
HIGH CAPACITY FEEDER (ONLY ONE ADDITIONAL 550-SHEET TRAY CAN BE ADDED TO HIGH CAPACITY FEEDER)			
Capacity⁴	2,000 sheets		
Sizes	Letter / A4		
Weights One-sided: Two-sided:	16 lb. bond to 65 lb. cover / 60 to 176 gsm 16 lb. bond to 65 lb. cover / 60 to 176 gsm		
Types	Bond Plain Paper Hole Punched	Letterhead Lightweight Cardstock Pre-Printed	Recycled
TOTAL CAPACITY			
Standard Device Capacity⁴	700 sheets		
Maximum Device Capacity⁴	3,250 sheets		
PAPER OUTPUT / FINISHING			
Capacity⁴	Up to 500 sheets		
Automatic Two-sided Printing	Standard		
FINISHER			
Capacity⁴	500-sheet tray, 50-sheet stapling		
MAILBOX			
Capacity⁴	Four 100-sheet bins		

DEVICE MANAGEMENT	
Network Protocols	TCP/IP: HTTP/HTTPS, Internet Printing Protocol, LPR / LPD, Raw Socket Printing/Port 9100, IPv4/IPv6, WSD LDAP Bonjour® / AirPrint™ Most protocols not in use can be disabled
Administrative Protocols	DHCP, SNMP, WINS, HTTP, HTTPS, TLS, SNTP, MDNS
REMOTE CONTROL PANEL	
	<ul style="list-style-type: none"> • Enables faster, more convenient technical support and user training • IT administrators and other authorized users can control the device remotely from a web page on any device • Remote user experience is identical to performing tasks directly at the device
XEROX® CENTREWARE® WEB SOFTWARE	
	<ul style="list-style-type: none"> • A web-based server application for network administrators that permits web browser-based device management from any workstation, whether running Windows or UNIX or any other operating system • Works with any SNMP-managed printer from any manufacturer • Provides help with device discovery and installations, health checks and troubleshooting, and device upgrades, as well as basic accounting and asset management
XEROX® EMBEDDED WEB SERVER – INTEGRATED DEVICE WEB PAGE	
Device Status	<ul style="list-style-type: none"> • Tray Status / Contents • Consumables Status • Billing / Usage • Quick Links • Online Support
Print Queue Viewing	Job print queue management — view and delete
Job Submission	Print-ready files (PS, PCL, PDF, XPS, JPEG)
Device Administration	Allows simple, remote installation setting of configuration options and management of the device
Browsers	Microsoft® Internet Explorer® Microsoft Edge™ Mozilla™ Firefox® Apple® Safari® Google Chrome™
REMOTE SERVICES	
Automated Meter Readings (AMR)	Automates the process of collecting and submitting meter reads for tracking and billing of Xerox® device usage. Eliminates the need for time-consuming end-user involvement and ensures that meter reads are submitted to Xerox on time.
Automatic Supplies Replenishment (ASR)	Automatically orders supplies for Xerox® output devices based on actual usage, eliminating the need to manually manage supplies inventory.
WHAT'S IN THE BOX	
	VersaLink C600 Color Printer Starter Capacity Print Cartridge: One of each (Cyan, Magenta, Yellow): 6,000 print capacity ⁶ , Black: 10,000 print capacity ⁶ Software and Documentation CD (Safety, Regulatory, Recycling and Disposal Guides, Print Drivers, and Warranty Statement) Installation Guide Quick Use Guides Power Cord

Xerox® VersaLink® C600 Color Printer

SUPPLIES AND ACCESSORIES	QUANTITY	PART NUMBER
SUPPLIES		
Standard Capacity Print Cartridges	Black: 6,000 standard pages ⁶ Cyan: 6,000 standard pages ⁶ Magenta: 6,000 standard pages ⁶ Yellow: 6,000 standard pages ⁶	106R03899 106R03896 106R03897 106R03898
High Capacity Print Cartridges	Black: 12,200 standard pages ⁶ Cyan: 10,100 standard pages ⁶ Magenta: 10,100 standard pages ⁶ Yellow: 10,100 standard pages ⁶	106R03903 106R03900 106R03901 106R03902
Extra-High Capacity Print Cartridges	Black: 16,900 standard pages ⁶ Cyan: 16,800 standard pages ⁶ Magenta: 16,800 standard pages ⁶ Yellow: 16,800 standard pages ⁶	106R03919 106R03916 106R03917 106R03918
ROUTINE MAINTENANCE ITEMS		
Drum Cartridges	Cyan: 40,000 pages ⁷ Magenta: 40,000 pages ⁷ Yellow: 40,000 pages ⁷ Black: 40,000 pages ⁷	108R01485 108R01486 108R01487 108R01488
Waste Cartridge	30,000 pages ⁷	108R01416
ACCESSORIES		
550-sheet Feeder		097S04949
2,000-sheet High Capacity Feeder (includes Caster Base)		097S04948
Cabinet (includes stabilizers)		097S04994
Caster Base		097S04954
Finisher (500 sheets, 50-sheet stapler)		097S04952
4-Bin Mailbox (100 sheets per bin)		097S04953
Productivity Kit with 320 GB HDD		497K18360
Wireless Network Adapter (Wi-Fi Kit)		497K16750
External Card Reader / RFID Kit		497K18380

¹ Declared print speed in accordance with ISO/IEC 24734.

² Maximum volume capacity expected in any one month. Not expected to be sustained on a regular basis.

³ Recommended average throughput is not a minimum, but is intended to cover a range of volumes for different environments.

⁴ Paper capacities are based on 20 lb. / 75 gsm stock; capacities will vary with different weight stocks.

⁵ Power states defined per ENERGY STAR® Program requirements for Imaging Equipment.

⁶ Average standard pages. Declared Yield in accordance with ISO/IEC19798. Yield will vary based on image, area coverage and print mode.

⁷ Approximate pages. Declared yield will vary depending on job run length, media size/orientation and machine speed. For more information visit: <https://www.office.xerox.com/latest/SUPGL-01.pdf>.

Return spent imaging supplies through the Xerox Green World Alliance collection/reuse/recycling program.

For more information, visit www.xerox.com/About-Xerox/Recycling.

For more information, visit us at www.xerox.com/Office.

Configurations vary by geography.